

**Thank you for purchasing a Mustard Bikes Fender Eliminator.
The following is a brief guide for installation of your
BMW S1000R(R) Fender Eliminator.**

1. Remove pillion seat using the key.
2. Disconnect the large white connector (Fender wiring harness) next to the alarm.
3. Remove the clamp screw and unclip the alarm, place it out of the way (do not unplug).
4. Gently squeeze and twist the alarm mounting bracket to remove it from the subframe.
5. Undo the three bolts underneath the stock fender and gently remove from the bike.
6. Remove the lenses from the indicators (make note of left and right) and left out the indicator reflectors.
7. Disconnect the indicator wires from the reflectors (make note of left and right) and feed out of the indicators.
8. Remove the indicator housings and fit to fender eliminator.
9. Disconnect the stock number plate light to remove the sub-harness from the stock fender.
10. Remove the rubber grommets from the stock fender and refit to the corresponding holes in the eliminator.
11. Feed sub-harness through smaller hole on the fender eliminator "wings" and route to the indicators.
12. You will need to splice the LED bolt into the sub harness. The use of crimp style male and female plugs is recommended and you may need to strip back the sheathe to reach the desired splice point.
13. Re-connect the indicator leads, reflectors and lenses, paying attention to left and right sides.
14. Feed all wiring through fender eliminator and offer assembly to the bike. Plug in sub-harness and check for operation. The LED bolt is polarity sensitive. If it does not light up switch the wires around and check again.
15. Secure the fender eliminator with the original bolts.
16. Refit alarm bracket, alarm and pillion seats in the reverse process to removal.

If you have any problems with installation feel free to contact us at help@mustardbikes.com for any queries.

