

**Thank you for purchasing a Mustard Bikes Fender Eliminator.
The following is a brief guide for installation of your
CF Moto 650 NK Fender Eliminator.**

1. Remove rider seat followed by the pillion seat, pull aside ECU (do not unplug).
2. Remove the forward 2 x M6 bolts from under the stock fender.
3. Remove the 2 x M6 bolts from the sides of the stock fender.
4. Remove the 2 x M6 bolts holding in the tail light from in the trunk.
5. Undo all indicator and number plate light plugs.
6. Remove the rear 2 x M6 bolts from under the stock fender and remove from bike.
7. Remove indicators from stock fender (17mm spanner) and fit to Fender eliminator.
8. Fit fender eliminator to bike using 2 x M6 bolts, 2 x M6 nuts (provided) to hold in tail light and 4 x M6 from under the fender eliminator.
9. Plug in all wiring and check for correct operation of all lighting.
10. The LED bolt is polarity sensitive. If it does not light up switch the wires around and check again.

If you have any problems with installation feel free to contact us at help@mustarbikes.com for any queries.

