

**Thank you for purchasing a Mustard Bikes Fender Eliminator.**  
**The following is a brief guide for installation of your**  
**2016 CB500F, CBR500R Fender Eliminator.**

1. Remove pillion seat using the key.
2. Locate orange, blue and white plugs for number plate light and indicators in clear shroud.
3. Disconnect plugs by lifting the tabs on the outside portion of the plug.
4. Remove 4 x 5mm Allen key bolts holding on the stock fender and gently remove from bike.
5. Remove 2 x Philips head screws, one on top, and one on the back of the stock fender.
6. Unclip the backing plate from the stock fender using a flat blade screwdriver (it clips in at its widest point).
7. Remove the Philips head screw on the back of each of the indicators.
8. Pull out the steel locking plate from the indicators (no need to undo the nut).
9. Remove the indicator and the mounting grommets.
10. Fit the supplied oval spacers to each mounting grommet and fit to fender eliminator.
11. Fit indicators to the fender eliminator in reverse process to removal.
12. Fit indicators to the fender eliminator in reverse process to removal.
13. Fit OEM number plate light plug to the LED bolt. The LED bolt is polarity sensitive. If it does not light up switch the wires around and check again.
14. Bolt the two parts of the eliminator together using the supplied counter sunk bolts but do not fully tighten.
15. Feed all wiring through fender eliminator and offer assembly to the bike.
16. Bolt fender eliminator to the bike with supplied 4 x 20mm long bolts / nuts but do not fully tighten.
17. Fit all wiring as original and check for correct operation.
18. Check fender eliminator alignment on the bike and fully tighten all bolts.
19. Refit pillion seat.

If you have any problems with installation feel free to contact us at [help@mustardbikes.com](mailto:help@mustardbikes.com) for any queries.