

**Thank you for purchasing a Mustard Bikes Fender Eliminator.
The following is a brief guide for installation of your
Suzuki SV650 Fender Eliminator.**



1. Remove seat using the key.
2. Locate rear fender wiring, near the tail light, and trace back to the connectors. Unplug from the main harness.
3. Undo the cable tie holding the wiring to the frame by lifting the tab on the cable tie head.
4. Remove 4x 10mm bolts from underneath the fender and gently remove fender from bike.
5. Remove the indicators by pulling the wiring through the rubber grommet and undoing the 8mm nuts.
6. If using the stock indicators fit to the fender eliminator in reverse process to removal.
7. Fit OEM number plate light plug to the LED bolt. The LED bolt is polarity sensitive. If it does not light up switch the wires around and check again.
8. Feed all wiring through the rectangular hole in the fender eliminator.
9. Fit 4x supplied 25mm bolt through fender eliminator and slide a spacer over the thread of each bolt.
10. Feed wiring through the wiring hole in the undertail of the bike offer fender eliminator up to the bike.
11. Line up and tighten each of the four Allen bolts.
12. Plug in indicators and LED bolt to OEM fender harness. Check lighting for correct operation.
13. Tidy up and bunch wires under fender eliminator with supplied cable ties.
14. Refit original removable cable tie in original location.
15. Refit riders seat.

If you have any problems with installation feel free to contact us at help@mustarbikes.com for any queries.

 [facebook.com/mustardbike](https://www.facebook.com/mustardbike)

 [mustarbikes.com](https://www.mustarbikes.com)